
CB32 control panel firmware upgrade procedure from ver. 3.XX to ver. 4.XX

Starting from CB32 control panel firmware ver. 4.00 new functions and options are added which, after firmware upgrade, need to be viewed and set. It can be done so with the panel connected to PC computer and CB32 Configurator software set up or, by direct edition of CB32 settings in the panel menu. In the first case, the below listed procedure steps should be followed:

- a) select control panel firmware ver. 3.00..3.99 in CB32 Configurator,
- b) save control panel settings to a PC file,
- c) upgrade CB32 firmware to ver. 4.XX,
- d) select control panel firmware ver. 4.00..4.29 in CB32 Configurator,
- e) view and select required settings,
- f) save the settings to control panel.

If settings are made directly in the panel's menu, it is recommended that the following submenus, listed in the same order as in instruction manual, are viewed and required settings made.

- 5.4. System Users->Disabling user*
- 5.5. System Users->Phone number*
- 5.6. System Users->Phone functions*
- 5.7. System Users->Remote type*
- 6.6. System times settings->Clock adjustment
7. Alarm notification by Elmes GSM module: view and made settings in all submenus except in submenu 7.1. (SMS center phone number).
9. System arming and signalling modes: view and made settings in all submenus.

* these settings should be made individually for every user